

BRISTAN

TAPS & SHOWERS

Installation Instructions & User Guide


Please leave these instructions with the end user

Product Code: EF KIT PK (D1)

Specifications

Dynamic Water Pressure

Please refer to your Tap Instructions



Maximum Static Pressure: 10.0 bar


Inlet Water Temperature

Cold Water Supply




Min: 5°C Max: 25°C

Hot Water Supply




65°C Recommended

Inlet Connections



1/2" BSP Flexible Tails with Isolation Valves

Tools You'll Need



Adjustable Spanner Pipe Cutter Hexagonal Key EasyFit Tool

Watch these Taps being Fitted

Scan the QR code to visit our YouTube channel and see a video guide of how these taps are fitted.



Alternatively visit www.youtube.com/BristanTV

Prior to Installation

All products manufactured and supplied by Bristan are safe provided they are installed, used correctly and receive regular maintenance in accordance with these instructions.


This product has been tested to the Water Regulations Advisory Scheme (WRAS) and satisfies the requirements of the Water Supply (Water Fittings) Regulations 1999 and current bylaws. For full Installation Requirements & Notes (IRN) please visit wras.co.uk/directory.

Isolation valves must be fitted to the inlet water supplies to ensure ease of future maintenance.


Before installing these taps the water supply must be thoroughly flushed in order to remove any swarf, solder etc.

This product must not be modified in any way as this will invalidate the guarantee.

Flexible Connecting Pipes



Pack Contents




Spare Parts

To replace any spare parts for your tap, why not scan the QR Code or visit www.bristan.com and search for your product.



Installation

1




Feed the base through the sink hole from the top.



If the surface the tap is being fitted to is over the stated tolerance; or you feel the tap needs extra stability, follow the alternative steps overleaf.


2



REMEMBER
Make sure the base is centralised when viewed from the front


Drop the Plain Inlet Connector into the base.

3



Turn the hexagonal key clockwise until the base is secured.


4




REMEMBER
hot on the left, cold on the right

Screw the flexible tails into the base.

DO NOT OVERTIGHTEN




Connect the hot and cold water connections.



Olive

Compression Nut

6




Grease the O-Rings using the Molykote Grease provided.

If the surface the tap is being fitted to is thin, follow the alternative steps overleaf

You will now need your EasyFit Tap.

Please refer to those instructions to check the Pack Contents and Tap Maintenance.

7




Place your desired tap onto the base.

8



Secure in place with the grub screws using the tool provided.

9



Thread the hexagonal key through the EasyFit tool and tighten the grub screws with an extra 1/2 turn.



General Cleaning

Bristan products are made from premium materials, with hand polishing and electroplated finishes.

Your taps or shower should be regularly cleaned with warm water, a mild pH-neutral liquid soap, and polished with a soft cloth. Any residues from soap, toothpaste, shampoos and shower gels can cause blemishes if not rinsed off straight after use.

Household bleaches and cleaners contain harsh chemicals and may damage the surface finish. Avoid using abrasive cloths, scouring pads, scrub sponges, steel wool or anything similar.

Some surfaces such as nickel and pewter may be affected by the dye found in some cloths, so it is also important to avoid hanging cloths on spouts.

Love Your Chrome



Bristan offers an effective chrome-friendly cleaning kit for use with your taps and showers. Scan the QR Code or search for 'CLEAN KIT01' on www.bristan.com.

Maintenance - Changing Tap

1

Isolate the water supply.

2

Unscrew the grub screws using the tool provided.

3

Remove your current tap and replace with the desired tap.

4

Secure with grub screws using the tool provided.

5

Turn on the mains water supply, letting the water flow for a few minutes to flush through the system.

Fancy a Change?

Scan the QR Code or search for 'EasyFit' on www.bristan.com to see taps compatible with your base.

Alternative Installation

1

Check the Pack Contents of your EasyFit Tap for the Reinforcing Plate and Washer (if required).

2

Turn the hexagonal key anti-clockwise to remove the backnut from the EasyFit Base.

3

Feed the base through the sink hole from the top.

4

Feed the Reinforcing Plate, & Washer (if required) and Backnut up to the underside of the sink.

5

Turn the hexagonal key clockwise to secure the EasyFit Base.

6

Proceed to Step 4 of the Installation Steps.

REMEMBER

Make sure the base is centralised when viewed from the front

Notes

Please use this space for any notes you or your installer may have regarding the installation/plumbing of this product.

Troubleshooting

Symptom	Cause(s)	Remedy
No flow or low flow rate	Partially closed isolation valve.	Open isolation valve.
	Instantaneous water heater cycles on and off as flow rate or pressure is too low.	Increase water flow rate or pressure through system.
	Head of water is below the minimum distance required.	Refer to your Tap Instructions for Pressure Specifications.
	Hot or cold water being drawn off elsewhere causing pressure changes or instantaneous boiler temperature changes.	Do not use other water outlets when using the taps.
	Airlock or partial blockage in the supply pipework or hoses.	Flush through pipework to ensure removal of debris and any airlocks.
Water dripping from taps	Water supply failure	Investigate water supply. Check your plumbing and heating systems for any faults.
	This is normal for a short time after using the taps.	This is caused by capillary action, the build up of water in the tap body.
Taps do not turn on	If water continues to drip, possibly due to the ceramic disc valves/cartridge	Refer to your Tap Instructions for Maintenance instructions or visit www.youtube.com/BristanTV to watch the procedure.
	Closed isolation valve.	Open isolation valve.
Wobbly Tap	Mains water supply turned off.	Turn on mains water supply.
	Grub screws are not tight enough at the base	Ensure the grub screws are fully tightened against the base
	Extra security may be required depending on the surface the tap is fitted to.	Refer to the Alternative Installation steps in order to fit the Reinforcing Plate.

At Bristan, we want to make things as easy as possible for our customers. That's why we offer solid guarantees on all our products, effective from the date of purchase, to give you peace of mind.

To start your free guarantee simply scan the QR code and register your product. Alternatively visit www.bristan.com/register.

For any other queries, please call our Customer Service on 0330 026 6273 where our expert team of advisors will be able to offer you any help and advice.

For full guarantee terms and conditions visit www.bristan.com/guarantees.



We Know & We Care