

# BRISTAN


TAPS & SHOWERS

## Installation Instructions & User Guide


Please leave these instructions  
with the end user

Product Code: GLL SKQUA1 MR (D1)


### Tools You'll Need




Soft Mallet




Silicon Sealant




Electric Drill




Safety Glasses




Hexagonal Key



Crosshead Screwdriver




Jigsaw



Flathead Screwdriver

### Pack Contents



### Prior to Installation

All products manufactured and supplied by Bristan are safe provided they are installed, used correctly and receive regular maintenance in accordance with these instructions.

This product has been tested to the Water Regulations Advisory Scheme (WRAS) and satisfies the requirements of the Water Supply (Water Fittings) Regulations 1999 and current bylaws. For full Installation Requirements & Notes (IRN) please visit [wras.co.uk/directory](http://wras.co.uk/directory).

Isolation valves must be fitted to the inlet water supplies to ensure ease future maintenance. Before installing any taps, the water supply must be thoroughly flushed in order to remove any swarf, solder etc.

The edges of this product can be sharp, especially in cut-out areas. Please wear gloves in order to prevent injury and do not hold the sink by the cut-out areas.

This product must not be modified in any way as this will invalidate the guarantee.

Before drilling into walls, check that there are no hidden electrical wires, cables or water supply pipes. This can be checked with the aid of an electronic detector.


If power tools are used do not forget to:

- Wear eye protection
- Unplug equipment after use


If in doubt, contact a registered plumber or your Local Water Authority or the Secretary of the Institute of Plumbing, address as follows:-

The Institute of Plumbing,  
64 Station Lane,  
Hornchurch,  
Essex,  
RM12 6NB, Tel: 01708 472791


### Dimensions



### Inlet Connections



Waste Connection Size: G 1 1/2"




Min Worktop Thickness: 30mm  
Max Worktop Thickness: 40mm


### Installation

1


Ensuring it's straight, place the  
Cutter Guide on the worktop  
and draw around the edge.  
Drill and cut the hole.



2



OR



**REMEMBER**  
Make sure the  
base is centralised  
when viewed from  
the front of  
the tap

Check the EasyFit base  
is correctly positioned.  
If you need to reinforce  
or adjust the base,  
**follow the steps overleaf.**

3

Gently knock  
all of the clips  
into place.

4

Screw the Overflow  
Connection into  
place

Cut the  
overflow  
pipe to the  
required size.

5

Fit the  
waste  
bodies to  
the sink.  
Secure  
in place  
with the  
screw.

**REMEMBER**

The waste  
pipes can be  
cut to size to  
fit the sink

6


Connect to the  
waste body.  
Carefully  
turn the sink  
upside-down.

8

Tighten the  
clamps to  
secure the  
sink.

9

Connect the  
waste to the  
domestic waste  
supply.



There is an optional  
connection for a water  
appliance.

Please refer to your appliance  
Fitting Instructions in order  
to connect the waste;  
or seal off with the  
rubber cap.

7

Using the corners  
for guidance, apply a  
suitable sealant along  
the outer ridge.  
Place the sink  
in position.

General Cleaning

Your Bristan product is made from a high quality composite resin; with 80% quartz and an anti-bacterial finish. Your sink should be regularly cleaned with warm water, a mild pH-neutral liquid soap, and dried with a soft cloth. Any residues from soap, food, toiletries etc. should be rinsed off straight after use.

Household bleaches and cleaners contain harsh chemicals and may damage the surface finish. Avoid using abrasive cloths, scouring pads, scrub sponges, steel wool or anything similar. Avoid scraping the sink basin or draining board with utensils or dropping heavy/sharp objects on to the sink surface. Do not place hot objects directly on to the sink.

### Adjusting/Reinforcing the EasyFit Base

1

Turn the hexagonal key anti-clockwise to remove the back nut from the EasyFit Base.

2

Position the top of the EasyFit base to preference.

4

Feed the Reinforcing Plate (if required) and Back nut up to the underside of the sink.

5

Turn the hexagonal key clockwise to secure the EasyFit Base.

6

Proceed to Step 3 of the Installation Steps.

REMEMBER

Make sure the base is centralised when viewed from the front of the tap

To replace any spare parts for your sink, why not scan the QR Code or visit [www.bristan.com](http://www.bristan.com) and search for your product.

Troubleshooting

| Symptom                            | Cause(s)  | Remedy   |
|------------------------------------|---|--|
| Sink is leaking                    | Loose waste connections                                 | Check waste connections for any leaks, ensuring all O-rings are in place.  |
|                                    | Seal around the sink edge/plug lets water through       | Add extra silicon sealant to those edges to ensure a water tight seal.   |
|                                    | Sink leaking from the overflow                          | Check the overflow seal and connections for damage. Ensure the screw is tightened.   |
| Water isn't draining from the sink | Sink is blocked.  | Refer to the Maintenance Section for Unblocking the Sink. If no blockage is found in the waste pipework, please contact your local Plumber for guidance. |
| Clamps do not grip the worktop     | Worktop is under 30mm                                   | Use a strong material e.g. wood to place under the worktop in order for the clamps to grip.  |
| Wobbly Tap/ Sink is Flexing        | Tap grub screws are not tight enough at the base        | Ensure the grub screws are fully tightened against the base. See your EasyFit Tap Instructions.  |
|                                    | Extra security may be required to support the tap base. | Refer to the Alternative Installation steps in order to fit the Reinforcing Plate.   |

### Notes

Maintenance - Unblocking the Sink

1

**IMPORTANT**  
Isolate the water supply before starting!

Remove the U-bend from the waste pipework.

2

Check for blockages and clean the pipework where necessary. Secure after cleaning.

3

Let the water flow for a few minutes and check connections for any leaks.

At Bristan, we want to make things as easy as possible for our customers. That's why we offer solid guarantees on all our products, effective from the date of purchase, to give you peace of mind.

To start your free guarantee simply scan the QR code and register your product. Alternatively visit [www.bristan.com/register](http://www.bristan.com/register).

For any other queries, please call our Customer Service on 0330 026 6273 where our expert team of advisors will be able to offer you any help and advice.

For full guarantee terms and conditions visit [www.bristan.com/guarantees](http://www.bristan.com/guarantees).

We Know & We Care