

Temperature Setting

1

Turn the shower on, letting the temperature stabilise.

2

Remove the cap, screw and temperature handle.

3

Turn cartridge spindle clockwise to decrease the temperature.

4

Turn cartridge spindle anti-clockwise to increase the temperature.

1 2

Reverse steps 1-2 to reinstall the cartridge and handle.

Maintenance - Cartridge Cleaning

1

Remove temperature and flow handle.

2

Unscrew the flow valve.

3

Remove temperature stop, retaining nut, and cartridge

4

Remove O-rings and soak all components in de-scaler and wash off in clean water. Examine all seals and replace if needed. Use WRAS approved silicon based grease on all seals.

5

Replace cartridge and turn spindle anti-clockwise to maximum temperature.

6

Replace nut and adaptor. Ensure the raised side is facing towards the back of the valve.

7

Turn cartridge spindle clockwise to decrease the temperature. Turn cartridge spindle anti-clockwise to increase the temperature.

8

Slide handle onto adaptor and turn clockwise until you meet resistance.

9

Reverse steps 1-2 to reinstall the valve and secure handles.

Servicing Intervals

To reduce the build up of limescale and to ensure this shower works to its maximum performance we recommend this shower is serviced every 6-12 months depending on the hardness of your water.

Spare Parts

To replace any spare parts for your shower why not scan the below QR Code and search for your product.



Riser Installation (not supplied with FZ SHXVOCTFF C)

1

Assemble the riser, attaching the hose retainer, slider and both the top and bottom brackets.

2

Use the assembled riser to mark the desired position for the riser on the wall.

3

Drill the marked holes.

4

Slide top bracket onto riser and secure to wall.

5

Insert riser rail into lower bracket and secure to the wall.

6

Slide hose through hose retainer before attaching the handset to the shower.

Troubleshooting		
Symptom	Cause	Remedy
No flow or low flow rate	Partially closed isolation valve.	Open isolation valve.
	Instantaneous water heater cycles on and off as flow rate or pressure is too low.	Increase water flow rate or pressure through system.
	Head of water is below the minimum distance required.	2 meters minimum required.
	Hot or cold water being drawn off elsewhere causing pressure changes or instantaneous boiler temperature changes.	Do not use other water outlets when using the taps.
	Airlock or partial blockage in the supply pipework.	Flush through pipework to ensure removal of debris and any airlocks.
Water dripping from shower	This is normal for a short time after using the shower.	This is caused by residual water tension, the build up of water in the shower.
	If water continues to drip, possibly due to the cartridge	Remove cartridge and clean, refer to 'Maintenance' section before starting any maintenance.
Shower does not turn on	Closed isolation valve.	Open isolation valve.
	Mains water supply turned off.	Turn on mains water supply.

Our Guarantee



At Bristan, we offer solid guarantees on all our products, effective from the date of purchase.

To start your free guarantee, register your product by visiting: www.bristan.com/register

For full guarantee terms and conditions visit: www.bristan.com/service-centre/guarantees.

Contact Us

Bristan Group Ltd.
A Masco Company


UK: Bristan Group, Pooley Hall Drive, Birch Coppice Business Park, Dordon, Tamworth B78 1SG.

EU: Masco Europe S.à.r.l. 14 Rue Strachen 6933 Mensdorf Luxembourg

Email Us: enquire@bristan.com

Website: www.bristan.com

Call Us: +44330 026 6273



Part of **BRISTAN GROUP**